

# Quick Start Guide\*

\*See owner's manual for complete assembly and operating instructions and important safety information before using this product.

## STEP 1



### Remove Outer Basket

Remove the Outer Basket by pulling the Easy-Grip Handle straight out.

## STEP 2



### Load Outer Basket

Arrange the food you are cooking on top of the nonstick Fry Tray.

## STEP 3



### Return Outer Basket to Unit

Use the Easy-Grip Handle to push the Outer Basket into the Unit until the Outer Basket clicks.

## STEP 4



### Power Unit On

Set the Time and Temperature. Follow instructions specific to your recipe.

## STEP 5



### Remove Outer Basket

Set the Unit on a secure, heat-resistant surface. Use tongs to remove food.

### NOTE:

- Before plugging the **Copper Chef AirFryer** into a power outlet, make sure all packaging material is removed from both outside and inside the Unit.
- After the cooking cycle has completed, the Operating Light will shut off and the Unit will beep. Check to see if your food is fully cooked and then transfer it to a serving dish.

**Wash All Components Before First Use**