

Size: 19.685" x 17.5"

1. Turn the temperature selector to the desired setting and lock the steam button in the DOWN position. For extended periods of dry ironing, empty the water from the iron.

DRY IRONING

1. Be sure there is water in the water tank.
2. Turn the temperature selector between settings 5 and 7.
3. Unlock the steam button to the UP position. If steam does not start, gently bump the soleplate on the ironing board a few times. If water drips from vents, turn the selector to a higher setting.

STEAM IRONING

- As soon as you pick up the iron, it will start heating again. Wait for iron to reheat completely before resuming operation.
- Once the iron reaches appropriate temperature, it will turn off after 30 seconds of inactivity if left on its soleplate or tipped over on its side. If left vertically on its heel rest, it will shut off after 8 minutes.

The automatic shutoff feature in your iron works as follows:

3-WAY AUTOMATIC SHUTOFF

3. When finished ironing, place iron on its heel rest, turn temperature selector to OFF and unplug the iron.
2. Once you determine the fabric type, set the temperature selector to the appropriate setting for your fabric. Once the iron reaches the selected setting and/or reduce starch.

Tip: If unsure of a garment's fiber, test a small area (on an inside seam or hem) before ironing. If there is a brown buildup on the soleplate, lower the temperature and/or reduce starch.

1. Use the fabric guide on the iron to select the proper temperature setting for the fabric.

SELECTING TEMPERATURE

2. Plug in the iron and let it stand on its heel rest. The power indicator light will turn on.
1. With the iron unplugged and the steam button locked in the DOWN position, use a clean measuring cup and pour water into the water-fill opening. Refill as needed.

FILLING WATER TANK

Tip: If unsure of a garment's fiber, test a small area (on an inside seam or hem) before ironing.

Important: For optimum performance, let the iron stand for 90 seconds before beginning to iron.

Note: Use ordinary tap water for ironing. Do not use water processed through a home softening system.

Remove any labels, stickers or tags attached to the body or soleplate of the iron.

GETTING STARTED

This product is for household use only.

How to Use

This product is for household use only.

How to Use

This product is for household use only.

How to Use

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.


This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.



Product may vary slightly from what is illustrated.

NEED HELP?

For service, repair or any questions regarding your appliance, please call our Customer Service Line at 1-800-465-6070. Please **DO NOT** return the product to the place of purchase. Also, please **DO NOT** mail product back to manufacturer, nor bring it to a service center. You may also want to consult the website listed on the cover of this pamphlet.

Warranty Information

(Applies only in the United States and Canada)

What does it cover?

- Any defect in material or workmanship provided; however, Spectrum Brands' liability will not exceed the purchase price of product.

For how long?

- Two years from the date of original purchase with proof of such purchase.

What will we do to help you?

- Provide you with a reasonably similar replacement product that is either new or factory refurbished.

How do you get service?

- Save your receipt as proof of date of sale.
- Visit the online service website at www.prodprotect.com/blackanddecker, or call toll-free **1-800-465-6070**, for general warranty service.
- If you need parts or accessories, please call **1-800-738-0245**.

How does state law relate to this warranty?

- This warranty gives you specific legal rights. You may also have other rights that vary from state to state or province to province.

What does your warranty not cover?

- Damage from commercial use
- Damage from misuse, abuse or neglect
- Products that have been modified in any way
- Products used or serviced outside the country of purchase
- Glass parts and other accessory items that are packed with the unit
- Shipping and handling costs associated with the replacement of the unit
- Consequential or incidental damages (Please note, however, that some states do not allow the exclusion or limitation of consequential or incidental damages, so this limitation may not apply to you.)

Are there additional warranty exclusions?

- **This warranty shall not be valid where it is contrary to U.S. and other applicable laws, or where the warranty would be prohibited under any economic sanctions, export control laws, embargos, or other restrictive trade measures enforced by the United States or other applicable jurisdictions. This includes, without limitation, any warranty claims implicating parties from, or otherwise located in, Cuba, Iran, North Korea, Syria and the disputed Crimea region.**

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only.

This product is for household use only

Size: 19.685" x 17.5"

RAYOVAC ARGENTINA S.R.L.

Por favor lea este instructivo antes de usar el producto.

INSTRUCCIONES IMPORTANTES DE SEGURIDAD

Cuando se utilizan aparatos eléctricos, siempre se debe respetar ciertas medidas de seguridad a fin de reducir el riesgo de un incendio, un choque eléctrico y (o) lesiones a las personas, incluyendo las siguientes:

- Lea todas las instrucciones antes de utilizar el producto.
- Use la plancha únicamente para planchar.
- No sumerja la plancha en agua ni en ningún otro líquido para evitar el riesgo de un choque eléctrico.
- Siempre apague [0] la plancha (vea la sección COMO USAR) antes de conectarla o desconectarla del tomacorriente. Nunca tire del cable para desconectarlo, sujete el enchufe para hacerlo.
- No permita que el cable entre en contacto con superficies calientes. Permita que la plancha se enfríe antes de guardarla. Enrolle el cable holgadamente alrededor de la plancha.
- Siempre desconecte la plancha cuando la llene o la vacíe y cuando no esté en uso.
- No haga funcionar la plancha si ésta tiene dañado el cable o si la plancha se ha dejado caer y se ha estropeado. A fin de reducir a un mínimo el riesgo de un choque eléctrico, no desarme la plancha. Acuda a una persona de servicio, calificada para revisar y efectuar las reparaciones necesarias. El armar la plancha incorrectamente puede ocasionar el riesgo de un choque eléctrico cuando la plancha esté en funcionamiento.
- Se requiere supervisión cuando cualquier unidad electrónica esté siendo usada cerca de los niños o por ellos mismos. No desatienda la plancha mientras esté conectada o cuando esté sobre la tabla de planchar.
- Pueden ocurrir quemaduras si se tocan las partes metálicas, el agua caliente, o el vapor. Tome precaución al invertir una plancha de vapor ya que puede haber agua caliente dentro del tanque. Evite los movimientos bruscos para no derramar agua caliente.
- Este aparato no está diseñado para ser usado por personas (incluído niños) con capacidad limitada física, mental o sensoriales disminuidas y falta de experiencia o conocimiento que les impida utilizar el aparato con toda seguridad sin supervisión o instrucción.
- Se debe asegurar la supervisión de los niños para evitar que usen el aparato como juguete.
- La plancha debe usarse o colocarse en una superficie plana y firme.
 - Cuando se coloca la plancha sobre el talón de descanso, asegúrese de que la superficie sea plana y firme.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

- La plancha no se debe usar si se ha caído, si se ha dañado o si está goteando.

INSTRUCCIONES ESPECIALES

- Para evitar sobrecargas, no opere ningún otro aparato de alto consumo de corriente en el mismo circuito.
- Si el uso de un cable de extensión es absolutamente necesario, un cable con un amperaje nominal igual o mayor que la potencia máxima de la plancha se utilizará. Un cable de menor capacidad puede resultar en un riesgo de choque eléctrico o incendio debido al sobrecalentamiento. Se debe tener cuidado de acomodar el cable de manera que nadie lo hale ni se tropiece.

CONSERVE ESTAS INSTRUCCIONES.

Este aparato eléctrico es para uso doméstico solamente.

ENCHUFE POLARIZADO Este aparato cuenta con un enchufe polarizado (un contacto es más ancho que el otro). A fin de reducir el riesgo de un choque eléctrico, este enchufe encaja en una toma de corriente polarizada en un solo sentido. Si el enchufe no entra en la toma de corriente, inviértalo y si aun así no encaja, consulte con un electricista. Por favor no trate de alterar esta medida de seguridad.

TORNILLO DE SEGURIDAD
Advertencia: Este aparato cuenta con un tornillo de seguridad para evitar la remoción de la cubierta exterior del mismo. A fin de reducir el riesgo de incendio o de choque eléctrico, por favor no trate de remover la cubierta exterior. Este producto no contiene piezas reparables por el consumidor. Toda reparación se debe llevar a cabo solamente por personal de servicio autorizado.

CABLE ELÉCTRICO

- a) El producto se debe de proporcionar con un cable eléctrico corto (o uno separable), a fin de reducir el riesgo de tropezar o de enredarse en un cable más largo.
- b) Existen cables eléctricos más largos y separables o cables de extensión que uno puede utilizar si toma el cuidado debido.
- c) Si se utiliza un cable separable o de extensión,
 - 1) el régimen nominal del cable separable o del cable de extensión debe ser, como mínimo, igual al del régimen nominal del aparato.
 - 2) Si el aparato es de conexión a tierra, el cable de extensión debe ser un cable de tres alambres de conexión a tierra.
 - 3) Uno debe de acomodar el cable más largo de manera que no cuelgue del mostrador o de la mesa, para evitar que un niño tire del mismo o que alguien se tropiece.

Nota: Si el cordón de alimentación esta dañado, en América Latina debe sustituirse por personal calificado o por el centro de servicio autorizado.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

Este producto puede variar ligeramente del que aparece ilustrado.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

Como usar

Este product es solamente para uso doméstico.

PRIMEROS PASOS

- Retire toda etiqueta o calcomanía adherida al cuerpo o a la suela de la plancha.

Nota: Utilice agua de la llave para llenar el tanque de la plancha. No utilice agua procesada por un ablandador de agua doméstico.

Importante: Para óptimo rendimiento al empezar a usar la plancha, enchúfela, enciéndala y déjela reposar en posición vertical por 90 segundos antes de usar

Consejo: Para evitar daño a las prendas, si desconoce la fibra de cierto tejido, ensaye primero sobre una superficie pequeña y planche una costura o ruedo interior.

LLENADO DEL TANQUE DE AGUA

1. Con la plancha desconectada y el botón de vapor hacia ABAJO, vierta agua en el orificio. Llene de nuevo cuando sea necesario.

2. Enchufe la plancha y colóquea sobre su talón. La luz indicadora de funcionamiento se ilumina.

PARA SELECCIONAR LA TEMPERATURA

1. Utilice la guía de tejidos que se encuentra en la plancha para seleccionar la temperatura apropiada para la tela que se va a planchar.

Consejo: Para evitar daño a las prendas, si desconoce la fibra de cierto tejido, ensaye primero sobre una superficie pequeña y planche una costura o ruedo interior.

2. Una vez que determine el tipo de tela, gire el selector de temperatura a la posición adecuada para su tela. Una vez que la plancha alcanza la temperatura programada, esta luz se apaga. Esta luz se ilumina y se apaga en intervalos durante el ciclo de planchado.

3. Cuando termine de planchar, coloque la plancha sobre su talón y gire el selector de temperatura a la posición OFF (apagado) y desconecte la plancha.

APAGADO AUTOMÁTICO DE 3 POSICIONES

El dispositivo de apagado automático de esta plancha funciona de la siguiente manera:

- La plancha se apaga automáticamente si permanece inactiva sobre la suela o de lado durante 30 segundos después de alcanzar la temperatura programada. Igualmente sucede si la plancha permanece inactiva verticalmente sobre el talón de descanso durante 8 minutos.

- La plancha comienza a calentar nuevamente en cuanto uno la levanta. Espere que la plancha se caliente bien antes de planchar.

PLANCHADO CON VAPOR

- Asegúrese de que haya agua en el tanque.
- Gire el selector de temperatura entre las posiciones 5 y 7.
- Suelte el botón de vapor hacia ARRIBA. Si no comienza a emitir vapor, golpee levemente la suela un par de veces. Si gotea a través de los orificios, ajuste a una temperatura más alta.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.

RAYOVAC ARGENTINA S.R.L.