

Quick Start Guide

PowerXL™ products that excel

GRILL AIR FRYER COMBO PLUS

See owner's manual for complete instructions and important safety information before using this product.

FOR AIR FRYING

IMPORTANT: Unpack all parts from the box and remove any clear or blue protective film on the components. Wash with warm, soapy water before first use (only select accessories are dishwasher safe).



STEP 1

Attach the Air Frying Lid to the appliance. Open the lid. Ensure that the Inner Pot is in place in the Base. If your recipe uses the Grill Plate, place the Grill Plate in the Inner Pot. Ensure that the Grill Plate sits evenly.



STEP 2

Arrange your food in the Inner Pot. Close the lid.



STEP 3

Turn the Control Knob to illuminate the presets on the Control Panel. Select one of the one-touch presets to set a cooking time and temperature or set the time and temperature manually. Press the Start Button to begin the cooking process.



STEP 4

Once the cooking timer has elapsed, open the lid and carefully remove food with tongs or oven mitts.

Quick Start Guide

PowerXL™ products that excel

GRILL AIR FRYER COMBO PLUS

See owner's manual for complete instructions and important safety information before using this product.

FOR GRILLING

IMPORTANT: Unpack all parts from the box and remove any clear or blue protective film on the components. Wash with warm, soapy water before first use (only select accessories are dishwasher safe).



STEP 1

Attach the Air Frying Lid to the appliance. Open the lid. Ensure that the Inner Pot is in place in the Base. Place the Grill Plate in the Inner Pot. Ensure that the Grill Plate sits evenly.



STEP 2

Close the lid, turn the Control Knob to select the Grill preset, and press the Start Button to preheat the appliance.



STEP 3

Once the appliance has preheated, "Add Food" will display on the Control Panel. Then, arrange your food on the Grill Plate in the Inner Pot. Close the lid and press the Start Button to continue the cooking process.



STEP 4

Once the cooking timer has elapsed, open the lid and carefully remove food with tongs or oven mitts.